

LEDVANCE VALUE Tunable White Remote Controller

MS-CV-DIM-RF 12/24V TW RM

Features


- Up to 30 meters connection range between the nearest LEDVANCE Value Tunable White Dimming Controller and the remote controller
- Perfectly compatible to work with LEDVANCE Value Tunable White Dimming Controller (Model: MS-CV-DIM-RF 12/24V TW)
- Each remote controller can pair up with one or many LEDVANCE Value Tunable White Dimming Controllers
- Red indication light would be light-on if any button on the remote controller is pressed in order to provide basic user interaction experience
- 4 zones of dimming controllers can be controlled by 1 remote controller separately thereby users would not be bothered by too many remote controllers on hand
- Each remote controller can save up to 3 memory scenes

Technical Parameters

Input and Output	
Output signal	RF(2.4GHz)
Working voltage	3VDC
Working current	<5mA
Standby current	<10µA
Standby time	1 year
Remote distance	30m

Environment	
Operation temperature	Ta:-30°C~+55°C
Case temperature (Max.)	Tc:+85°C
IP rating	IP20

Mechanical Structures and Installations Guide



Note: Please install the 3V 2032 battery cell first inside the battery case at the back side before using the remote controller.

How to fix the back holder of remote controller at somewhere if you are worried about missing it?

- a. Fix the back holder on the wall with 2 screws;
- b. Use the adhesive back tape to fix the back holder on the wall.



LEDVANCE VALUE RGB Remote Controller

Application highlights for standby mode

- ! To extend the battery life, the stepless color touching wheel will be in sleeping mode that any touches on the color wheel would not trigger the stepless color change.
- ! To terminate the sleeping mode, you may press any other button except the on/off button to wake it up, thereby you can use the color wheel to change the colors according to the instruction.

Match Remote Control (two match ways)

Simple guide of pairing up and unting the remote controllers and dimming controllers

Method A - Use match button

Shortly press the match button on the dimming controller and the signal blue light on the dimming controller will start to flicker;

Immediately press "1" or other number of zone button on the remote controller;

Method B - Restart the power

Turn off the power and turn on the power;

Immediately press "1" or other number of zone button on the remote controller for 3 times;

When the blue signal light on the dimming controller flickers quickly for 3 times, the dimming controller and remote controller are pair-up successfully.

Guide of unting the remote controllers and dimming controllers

Method A - Use match button

Press the match button continuously for 5 seconds.

Method B - Restart the power


Turn off the power and turn on the power again.

Immediately press the "1" or other number of zone button on the remote controller for 5 times.

The remote controller would be untied with the dimming controller after the blue signal light flickers 5 times.

LEDVANCE VALUE RGB Remote Controller

Key function



On/Off: Short press turn on/off all zone light.

1,2,3,4 zone setting: Shortly press the selective number of zone button, the strip in this zone will be lighted on. Press and hold on for 2 seconds for selective zone button will turn off the strips within this zone. Please note that the zone setting should be done whilst pairing up the remote controller and the LEDVANCE Value Dimming Controller.

Color wheel: By touching and moving on the color wheel, various types of color temperature can be demonstrated accordingly.

Bright+/-: Shortly press the 2 buttons can reduce or increase the lighting output of the strips. Users can also press the button continuously for 1-6 seconds to enjoy the continuously dimming functions up to 256 levels.

3 memory scene: Users can save the demonstration as memory scene by pressing the button for 2 seconds. Once users wonder to demonstrate the scene again, they can shortly press the button to recall the saving scene. Please note that 4 zones of setting would be recalled or saved synchronously.

Warnings

- a Please read all the instructions carefully before you start to do any installation
- b Please pay attention to the polarity of the battery cell before inserting the battery cell inside the remote controllers
- c If you will not use the remote controllers for a long time, please kindly remove the battery to avoid the potential damage to the remote controller caused by expiration of battery cell
- d If the sensitivity of the remote controller becomes worse and worse when none of the signal amplifier is installed in the communication area, please consider to change the battery cell
- e If you cannot give any instruction to the dimming controllers and the strip, please kindly re-do the pairing up following the guide in this sheet
- f Please do not throw the remote controller hardly on floor or walls. Any intensive physical damage made by users will not be secured for warranty replacement
- g Please only use the remote controller within indoor area. The dimming controllers and remote controllers are not suitable for any outdoor application and environment

朗德万斯照明有限公司
广东省佛山市禅城区工业北路1号之一
邮编: 528000
客服热线: 400 882 1830
www.ledvance.com.cn

LEDVANCE Pte Ltd.
988 Toa Payoh North, # 03-06,
Singapore 319002

LEDVANCE Sdn. Bhd. (1166537-U)
100.7.009, 129 Offices, Block J, Jaya One
No. 72A, Jalan Universiti,
46200 Petaling Jaya,
Selangor Darul Ehsan, Malaysia

LEDVANCE Pvt. Ltd.
1201-1202, 12th Floor, Signature Towers, Tower - A,
South City - I, Gurugram - 122001, Haryana (India)
Consumer care (Name and address as per above),
Consumer care Tel. No. 0124-4150100
E-mail id: customercare@ledvance.com
www.ledvance.in

(주)레드밴스
서울시 강남구 삼성로554예성빌딩6층
(우편번호 06165)
전화번호: +82 80 4891 700
www.ledvance.co.kr

LEDVANCE Prosperity Co. Ltd.
Room 4007-4009 Office Tower,
Convention Plaza, 1 Harbour Road,
Wanchai, Hong Kong

LEDVANCE Middle East FZE
Jebel Ali Free Zone
JAFZA 16, Office 603
P.O. Box 17476, Dubai – UAE

LEDVANCE Pty Ltd
ABN 34 050 103 181
Suite 2.1A
394 Lane Cove Road
Macquarie Park NSW 2113,
Australia
Ph +61 29481 8399/1300 467 726
www.ledvance.com.au